

## Borehole Extensometer


### Purpose

To monitor sub-surface settlement indicating the total settlement as well as the incremental settlement at the depth of each magnet.

### Application

Monitor settlement or heave in excavations, foundations, and embankments.

Monitor settlement or heave above tunnels and other underground openings.



*Overview of the magnetic extensometer*



*Magnetic extensometer*