

## **Water Standpipe**

### Purpose

To monitor ground water level at atmospheric head

### Water Standpipe Application

1. Monitor rises or falls of water level inside the pipe (installed below ground) with respect to the ground during excavations and underground openings.
2. Measure water levels in water wells.



*Water level Indicator*



*Monitoring water levels*



*Water Standpipe Installation*